
+22 - +90 intermediate
turn left
T8-
T8+
T9+
T9-
T0+
turn right
T9+
+90 pos
P+90
T8+
P-22
turn right equalizer
T9+
+22 pos
T9+
P0
T9-
0 - +22 intermediate
T8-
P+22
T8+
turn right equalizer
T9+
0 pos
T8+
turn left equalizer
T9+
P-22
T9-
0 - -22 intermediate
P0
T8-
T8+
-22 pos
T8+
turn left equalizer
P-22
T9+
T9+
-90 pos
T8+
turn left
P-60
T8+
T8-
T8+
P-90
T9+
-60 pos
turn right
T9+
-22 - -90 intermediate
T9-